

## Assembly instructions: Folding trays

### Step 1

Place a mat (if available) on the floor and place the folding tray in the middle of the mat or at the DESIRED location on the floor. Leave the outer walls lie on the tub so long.

### Step 2

Insert one side of the included aluminum brackets into the orange pockets so that the bracket faces outwards.

Optionally, the angles can point inwards if the folding tray is to be anchored to the floor with screws (not included in the scope of delivery).



### Step 3

If necessary, place the insert mat (not included in the scope of delivery) in the tub.

### Step 4

When all angles are plugged in, fold the sides of the tub at right angles one after the other, so that the angles are below the tub to stabilize it.

### Step 5

Guide the twist locks through the oval eyelets at the four corners of the folding tray (see illustration) and turn the LOCKS left or right to a vertical position.



### Step 6

To drive onto the folding tray, the twist locks **MUST** be opened and all angles on the corresponding side removed.

**Tip:** Use our SORB<sup>®</sup>XT Mobile Kit for safe and space-saving storage.